

Mini Fixing Instructions

The wall plugs provided with your Adjustabail are suitable for all types of wall, including brick, stone, concrete and plasterboard. Check the desired wall for hidden cables or pipes, mark and drill a 5.5mm diameter hole, 40mm deep. The plug should be a tight fit in the hole and you will need to gently tap it until it is flush with the wall. Screw the 4mm x 35mm screw into the plug until 6mm is left protruding from the wall.

Carefully hook the Adjustabail on the back of the object over the screw. The screw should easily slide into the recess in the Adjustabail. If the object wobbles about, tighten the screw a bit at a time until you can feel the Adjustabail sliding with a small resistance over the screw. Cover the screw head with the supplied dot and paint it the same colour as the wall. **DO NOT** force the Adjustabail over the screw – you may detach it from the back of the object.

Please note that it is the responsibility of the purchaser to ensure that the integrity of the mounting wall is sufficient to carry the size and weight of the glass panel. We cannot be held responsible for any damage or breakages.