

# Bracket Fixing Instructions

---

Decide where you want to hang your object, check the wall for hidden cables or pipes, position the bracket roughly level on the wall and mark through the holes with a pencil. The wall plugs provided with your Adjustabail are suitable for all types of wall, including brick, stone, concrete and plasterboard.

Drill 5.5mm diameter holes 40mm deep as accurately as you can to the pencil marks. The plugs should be a tight fit and you will need to gently tap them until they are flush with the wall. Screw the bracket to the wall, but don't

over tighten the screws. Cover the screw heads with the dots supplied and paint them the same colour as the wall.

Position the slug on the back of your object into the bracket ensuring it is properly seated and adjust so the object is level.

**Please note that it is the responsibility of the purchaser to**

**ensure that the integrity of the mounting wall is sufficient to carry the size and weight of the glass panel. We cannot be held responsible for any damage or breakages.**

